

ELECTRONIC THERMOMETER WITH MAX / MIN

RANGE OF TEMPERATURES: - 20 ° C to + 50 ° C

BATTERY INSTALLATION:

- Open the battery compartment cover.
- Install 1 AAA 1.5V battery, respecting the polarity.
- Close the compartment cover.




REF. 129021200

FEATURES:

- Display of temperature and maximum / minimum temperatures.
- Press the "Clear" button to erase the max and min temperatures.
- The memory is also automatically reset when the batteries are replaced.
- Press the "° C / ° F" button to choose between the ° C or ° F unit.

PRECISIONS AND PRECAUTIONS ON THE USE OF BATTERIES:

- Throw a used battery in nature or garbage pollutes and prevents recovery of valuable materials. It is therefore important to limit the consumption of batteries and observe the following instructions:
 - focus on alkaline batteries (which last longer than salt cells) and when it is possible, rechargeable batteries
 - Deposit used batteries and accumulators in the specific containers available at traders. Thus, metals will be valued and will not pollute the environment because they contain heavy metals dangerous to health and the environment (mainly cadmium and nickel)
- The batteries must be inserted respecting the polarity indicated on the device and on the battery. Incorrect positioning can either damage the unit or cause leaking of batteries, either to the extreme, cause a fire or battery explosion.
- To ensure proper operation, the batteries must be in good condition. In case of anomaly in operation of the device, put new batteries.
- Never try to recharge non-rechargeable batteries. They could sink, warm up, and cause fire or explosion.
- Replace all batteries at the same time. Never mix saline batteries with alkaline or rechargeable batteries.
- Used batteries should be removed from the device.
- Also, remove the batteries from your device if you do not use it for a long time, otherwise the batteries may leak and cause damage.
- Never try to short the terminals of a battery.
- Never throw batteries into a fire, they may explode.
- Accumulators must be recharged by an adult.
- Remove the batteries from the device before recharging them.
- We advise the adult to monitor the child when changing the batteries so that these instructions are respected or to replace the batteries themselves.
- If a battery is swallowed, immediately consult your doctor or nearest Poison Control Center. Do not forget to take the device with you.



UKAL

Le monde de l'élevage